

線性滑軌壽命計算步驟說明

Linear Guideway Life Calculation Operation Manuals

1. 打開壽命計算程式介面即可開始操作
Start operation



2. 依序輸入設定條件及規格即可計算
Enter setting conditions and specifications

